



BATTERY OPERATED HYDRAULIC

SERIAL NUMBERS:

SPARE PARTS LIST NO

CRIMPING TOOLBC63

SEE NOTES ON PAGE 2

BC63P2:

ITEM NO.	PART NO.	DESCRIPTION	QTY	ITEM NO.	PART NO.	DESCRIPTION	QTY
01	BC30-01	Left Housing	1	49	BC63-49	Screw	2
02	BC30-02	Right Housing	1	50	SC60-77	Bolt	1
03	BC30-03	Oil Reservoir Cap	1	51	SC60-76	Parallel Screw	1
05	BC63-05	Pump Body	1	52	SC60-08	Screw	1
06	BC30-06	Screw	2	53	SC60-04	Release Spring	1
07	BC30-07	Spring	2	54	SC60-03	U-Type Crimping Head	1
08	BC30-08	Screw	2	60	SC60-01	Upper Die Holder	1
09	Х	Steel Ball	2	61	SC60-74	Lower Die Holder	1
10	BC30-10	Spring	2	64	BC63-64	Fixed Ring	1
11	Х	Steel Ball	5	65	BC30-65	Screw	1
12	BC30-12	Spring	1	66	BC30-66	Power Set	1
13	X	O-Ring	1	67	BC30-67	Release Rod	1
14	х	Back-up Ring	1	68	BC30-68	Bolt	1
15	BC30-15	Gauge coupler	1	69	BC30-69	Screw	1
16	х	Washer	1	70	BC30-70	Spring	1
17	BC30-17	By-Pass Cartridge	1	71	BC30-71	Supporting Rod	1
18	BC30-18	By-Pass Cartridge Spring	1	72	BC30-72	Screw	4
19	х	By-Pass Cartridge Set	1	90	BC30-90	Motor Fixed Ring	1
20	BC30-20	Steel Ball	4	91	BC30-91	Monitor Protector	1
21	BC30-21	Screw	4	92	BC30-92	Cable Tree	1
22	Х	O-Ring	2	93	BC30-93	Screw	3
24	х	O-Ring	1	95	BC30-95	Filter	2
29	BC30-29	Pin	1	96	BC30-96	Snap Ring	2
30	X	Back-up Ring	1	97	BC30-97	Plastic Fixer	1
31	BC30-31	Piston Spring	1	98	BC30-98	Screw	4
32	х	Ring	1	99	BC30-99	Flying Ring	2
33	BC30-33	Piston	1	100	BC30-100	By-pass Cartridge Cover	1
34	Х	O-Ring	1	101	BC30-101	Switch	1
35	BC30-35	Piston	1	102	BC30-102	Pin	1
36	Х	O-Ring	1	103	BC30-103	Spring	1
37	BC30-37	Release Stem	1	105	BC30-105	Screw	2
38	X	O-Ring	1	109	BC30-109	Screw	1
39	BC30-39	Oil Reservoir	1	110	BC30-110	Screw	1
40	BC30-40	Plug	1	111	BC30-111	Screw	5
43	SC60-10	Ram Spring	1	112	BC30-112	Screw	2
44	SC60-09	Axis	1	113	BC30-113	Сар	1
45	X	O-Ring	1	114	BC30-114	Screw	1
46	х	Back-up Ring	1	115	х	Back-up Ring	1
47	SC60-11	Ram	1	116	BC30-116	Ball Seat	1
48	SC60-13	Spring	1	117	X	Washer	1
				118	BC30-118	Needle	1

IMPORTANT NOTE:

Up to Serial No. DO4716 – If the battery or charger unit requires replacement, order both BP12 (Battery Pack) and CU12 (Charger Unit) together

From Serial No. DP2351 – If the battery or charger unit requires replacement, order either BP12 (Battery Pack) or CU12 (Charger Unit) according to the requirement

IMPORTANT

WHEN ORDERING SPARES YOU MUST STATE THE FULL PART NUMBER AND THE PRODUCT SERIAL NUMBER – FROM THE LABEL. TO PROTECT YOU WARRANTY ALWAYS USE GENUINE HI-FORCE PARTS.

WWW.HI-FORCE.COM